



Note: mount Q2 heatsink upwards!
tube socket on bottom side!